USER MANUAL YM94

Tecnovita

by BH

We would like to thank you for purchasing the YM94 hand warmer and for the trust you have placed in ***Tecnovita by BH***. To use the unit correctly, first read through the whole manual before using it.

Description and contents of the box

Characteristics

- 3 modes: hand warmer, LED lamp (luminosity 8000 – 10000 mcd), mobile phone battery charger
- Rechargeable Lithium-Ion battery
- USB connector
- Autonomy: Up to 4 hours of use
- Tiempo máximo de carga 4 horas

Description

A Main unit

1 – USB input
2 – On/Off button
3 - heat panel
4 – LED lamp
5 – Slot for strap



B USB cable (white)

C Mobile phone battery charger cable (black)

D 3 connectors

E Strap

Charging the battery

• Charge the battery fully before using the unit for the first time or if it has not been used for a prolonged period

1. Use the white cable (B) to charge the battery in your hand warmer. Plug the mini USB into the USB input on the unit (1)
2. Connect the USB output on the cable to a corresponding USB device (5V (0.5-1A)) e.g. PC, Laptop, USB adaptor.
3. The On/Off button will light up red, indicating that the unit is charging. All of the functions on the unit will be disabled while the battery is charging.
4. Charge time takes approximately 4 hours. When the On/Off button lights up green this indicates that the unit is fully charged.

• The On/Off button will flash red when the battery is about to die. Charge the battery as soon as possible.

• Ambient temperature for charging the unit: 0ºC – 40ºC

When connecting the unit to a device (PC, Laptop, USB adaptor, etc.) make sure the output is appropriate (5V (0.5-1A)). Otherwise the unit may suffer damage.

• If you notice interference on the television or radio while charging the battery, move the unit away from these devices.

Hand warmer mode

1. To switch the device on, press and hold the ON/OFF button (2) for 3 seconds. The light on the On/Off button will flash red, green and yellow for 5 seconds while it checks the battery status (See section for light indicator).
2. The On/Off button (2) will now light up orange to indicate that it is operating in hand warmer mode.
3. To switch the device off, press and hold the ON/OFF button (2) for 3 seconds. (To switch to Lamp mode press button (2)).

• To use the unit in hand warmer mode, place the unit inside your pocket or hold it in your hand.

• When the battery is about to die the On/Off button will flash red..

• The hand warmer function will be disabled while the unit is charging.

• When using the hand warmer in extremely cold environments, it is advisable to wrap the unit in cloth to maintain the temperature.

• Only the panel section (3) of the unit gives off heat

Hand warmer specifications

Average temperature 40ºC – 45ºC

Autonomy: 4 Hours

• This information is based on an ambient temperature of 25ºC

• The unit will reach maximum temperature within 3 minutes

• Battery duration depends on environmental conditions

LED lamp mode

1. To switch the device on, press and hold the ON/OFF button (2) for 3 seconds. The light on the On/Off button will flash for 5 seconds while it checks the battery

status (See section for light indicator). This unit go into hand warmer mode. To switch to LED lamp mode press the On/Off button (2)).

2. The LED lamp will light (4).
3. To switch the device off, press and hold the ON/OFF button (2) for 3 seconds. (To switch to mobile phone battery charger mode press button (2)).

• When the battery is about to die the On/Off button will flash red..

Mobile phone battery charger mode

1. To switch the device on, press and hold the ON/OFF button (2) for 3 seconds. The light on the On/Off button will flash for 5 seconds while it checks the battery status (See section for light indicator). This unit go into hand warmer mode. To switch to mobile phone battery charger mode press the On/Off button (2) twice. The On/Off button will flash red/green.
2. Plug the mini USB on the mobile phone battery charger cable (C) (black) into the input on the unit (1). Fit the corresponding mobile phone connector (D) to the other end of the cable. Finally, plug the connector into your mobile phone.

• The hand warmer and LED lamp functions are disabled while the unit is in mobile phone battery charger mode.

General safety instructions

• Inspect the unit before use to ensure that it is in good working condition. If you notice a defect or missing parts, contact the distributor of the product.
• The unit must not be used by children or the disabled without suitable adult supervision.
• Do not use the unit in damp/humid surroundings and prevent it from getting wet. Do not touch the unit with wet hands while it is operating.
• Do not expose the unit to high temperatures. Store it in a dry place.
• Do not place the unit on cooker tops, microwave ovens or any other hot or high pressure surfaces.
• Do not use the unit in environments where there is a risk of fire or explosion.
• Handle the unit with care, do not knock it.
• If the liquid inside the unit comes in contact with your eyes, rinse them immediately with clean water and contact your doctor.
• To avoid burns, do not use the unit while sleeping. Stop using the unit if you feel too hot or experience discomfort.
• If you suspect that the unit is not working properly, if you notice a strange smell, etc., Stop using it immediately. Do not attempt to repair, disassemble or modify the unit. Unauthorised repairs may cause injury, in addition to breaking the terms of the warranty. Contact your technical assistance service.

Light indicator

Light	Status
Flashing red, green and orange	**Preparing for use**
Flashing red and orange	**Unit preparing to charge**
Flashing red	**Low battery, charge the unit**

Technical specifications

Reference	**YM94**
Input	**5V DC, 1A**
Output	**5V DC, 1A**
Dimensions	**94mmx66mmx17.5mm**
Weight	**60g**
Charge temperature range	**0ºC – 40ºC**
Operation temperature range	**-10ºC – 40ºC**
Lithium-Ion battery capacity	**3.7V, 1450mAh**
Charge time	**4 Hours approx.**
Autonomy	**Up to 4 Hours**

Possible problems

Problem	**Possible causes**	**Solution**
This unit does not heat up in hand warmer mode.	- **Low battery** - **Lamp/Charger mode**	- **Charge the battery** - **Heat mode not compatible with other modes Change mode**
On/Off button does not work	- **Unit charging** - **Low battery**	- **Functions are disabled while charging** - **Charge the battery**
Battery life is much shorter than stated in the manual	- **The unit has not been fully charged** - **The unit has reached the end of its useful life** - **Ambient temperature too low**	- **Charge the unit fully** - **Replace the unit.** **- Wrap the unit in cloth**
Charge time too long	**- Ambient temperature too high/low**	**- Charge the unit at an ambient temperature of 0ºC-40ºC**
The unit does not charge	**- The USB connectors are not connected correctly** **- The output on the USB device is not 5V.**	**- Connect the USB outputs correctly** **- Use a device with 5V output**

Cleaning and maintenance

• Allow the unit to cool down and clean it with a soft cloth. Do not allow the appliance to come into contact with water or any other liquid. Do not immerse the appliance in liquid to clean it. Do not use alcohol or abrasive products.

• Waste electrical or electronic equipment and Lithium-Ion batteries must not be disposed of in household waste, but at the collection points designated by the town council or local authorities.
• For more information about how to dispose of waste electrical and electronic equipment, contact your town hall, waste disposal service or the establishment where you purchased the product.

Warranty

This product is guaranteed for 2 years in accordance with that stated in Directive 1999/44/EC of the European Parliament and of the Council 25th May, 1999, regarding certain aspects of the sale of consumer goods and associated guarantees, incorporated into Spanish Law by virtue of Law 23/2003, 10th July; Guarantees on the sale of consumer goods.
To this effect, EXERCYCLE, S.L. VAT nº B-01029032, with business address c/ Zurrupitieta 22, Vitoria, Spain, guarantees this product.

Date of purchase.-	Purchased in.-
Purchaser.-	Dealer stamp.-

Please keep the receipt as proof of purchase.
Should you have any queries please do not hesitate to phone our customer service line:
902 170 258

EXERCYCLE,S.L.
c/ Zurrupitieta, 22 • 01015 VITORIA (Spain) • Tel. 945 29 02 58
Fax: +34 945 29 00 49 • e-mail: info@bhfitness.es

AFTER SALES SERVICE SPAIN
Tel: +34 945 292 012 / 902 170 258 • Fax: +34 945 56 05 27

www.tecnovita.eu